

# GCP-2 Series QUICK REFERENCE GUIDE



# GCP-2 Series QUICK REFERENCE GUIDE

## **CAUTION**

**THERE ARE EYE AND OTHER HAZARDS ASSOCIATED WITH THE USE OF THE GCP-2. READ AND FOLLOW THE GCP-2 OPERATOR MANUAL BEFORE USE. NEVER OPERATE THE GCP-2 WITHOUT THE PROPER LASER SAFETY TRAINING. NIGHT VISION GOGGLES ARE REQUIRED TO VIEW THIS IR LASER. THE SAFETY SLIDE SHOULD BE KEPT IN THE SAFE POSITION AT ALL TIMES UNLESS FIRING THE LASER. THE GCP-2 CAN BE DETECTED BY ANY PERSON WITH A NIGHT VISION DEVICE.**



### **SAFETY SLIDE**

In the SAFE position, the HI/LOW power selector is revealed and the laser is unable to be fired, except through the remote switch. In the ARMED position, the fire button is revealed and the laser is ARMED.



### **HI/LOW POWER SELECTOR**

The Hi/Low power selector permits reduction of the laser power to eye-safe levels for training and force-on-force maneuvers. To select Hi or Low rotate the Hi/Low power selector 180° clockwise or counter-clockwise with a small slot screwdriver (not provided).



### **BATTERY INSTALLATION**

Set the Safety Slide to the SAFE position. Remove the battery cap by turning the retaining knob counter-clockwise. Pull and turn the battery cap away from the body of the GCP-2 until a stop occurs. Insert the batteries according to the printed symbols. Replace battery cap and turn the retaining knob clockwise until it the battery cap is tightly secured.



### **FIRING THE LASER**

To fire the GCP-2 move the safety slide to the ARMED position and press the red fire button. When the remote switch is installed, either the button on the remote switch or the GCP-2 unit will fire the laser.



### **FOCUSING THE BEAM FOR THE GCP-2**

The focus ring can be adjusted to change the size of the beam. Turn the ring counter-clockwise to make the beam smaller and increase range. Turn the ring clockwise to make the beam wider.



### **ADJUSTING THE POWER**

Turn the knob counter-clockwise to decrease power and decrease the brightness of the laser beam. Turn the knob clockwise to increase power and brighten the laser beam.